

Recording videos



Home / Recording videos / Auto video mode

AUTO Auto video mode

Recording videos

To use the DxO ONE in video mode, change the shutter button on the screen from the photo icon to the video icon.

The shutter button on the screen will change to Video mode.



By default, video recording starts in HD and Automatic mode (1080p, 30 f/s). You can also switch to Manual mode or Slow-Motion mode.

To start recording, press either the shutter button (video icon) on the iPhone screen, or the shutter button on the DxO ONE. The application shutter button will turn red when recording, and the application will display the elapsed time. The DxO ONE OLED screen will show a flashing dot to show recording is taking place.

In video mode, the camera automatically focuses on the center of the screen, and face detection is disabled. We recommend focusing before you start filming, but you can change where you're focusing during shooting by tapping on the desired place on the screen. If you want subjects on different planes to be sharp, you can extend the depth of field by going into Manual mode and stopping down the iris to a smaller aperture (see section ["Shooting settings"](#) pour plus de détails).

In Auto video mode, the video recorded is in the H264 format in Full HD or "1080p" definition, i.e. 1920x1080 pixels, at a rate of 30 frames per second.

LANGUAGES

- Français
- Deutsch
- Español
- 日本語

RELATED POSTS

[Shooting settings](#)

< MANAGING FOCUS

SLOW MOTION VIDEO MODE >


Receive our newsletter

SUBSCRIBE

Follow us



Choose your language



DxO ONE

- Overview
- Image quality
- iOS App
- Design
- Press & Testimonials
- Find a retailer

VISIT OUR PARTNER SITES :

PHOTO SOFTWARE

- DxO PhotoLab
- DxO FilmPack
- DxO ViewPoint

DxOMark ↗

PRESS & TESTIMONIALS

- DxO ONE Camera
- Photo Software

Imaging Quality ↗

LEARN AND SUPPORT

- Product How-To's
- Support
- Forum
- Software Registration

COMPANY

- About
- Careers
- Press
- Contact

SHOP

- DxO ONE Camera & Accessories
- Photo Software
- Find a Retailer
- My Account