

Getting started

Home / Getting started / Composition grid



Composition grid and shooting settings Getting started

The DxO ONE iOS application has a built-in composition grid and displays the camera's principal shooting settings (exposure, white balance, and iPhone battery level).




- To display the grid and settings, swipe down (when the iPhone is positioned horizontally).
- To hide them, swipe up.

The grid consists of two vertical lines and two horizontal line and helps you frame your shot according to the "rule of thirds"

The shooting settings listed at the top of the screen include:

- 1 Metering mode.
- 2 Focus mode.
- 3 White balance settings.
- 4 iPhone battery level.



Along the bottom of the screen:

- 5 Exposure indicator.
- 6 Shutter speed.
- 7 Aperture.
- 8 ISO sensitivity.

LANGUAGES

- Français
- Deutsch
- Español
- 日本語

RELATED POSTS

No related post

< CAPTURE SCREEN

BASIC FUNCTIONS >

Receive our newsletter

SUBSCRIBE

Follow us



Choose your language



DxO ONE

Overview
Image quality
iOS App
Design
Press & Testimonials
Find a retailer

VISIT OUR PARTNER SITES :

PHOTO SOFTWARE

DxO PhotoLab
DxO FilmPack
DxO ViewPoint

DxOMark ↗

PRESS & TESTIMONIALS

DxO ONE Camera
Photo Software

Imaging Quality ↗

LEARN AND SUPPORT

Product How-To's
Support
Forum
Software Registration

COMPANY

About
Careers
Press
Contact

SHOP

DxO ONE Camera & Accessories
Photo Software
Find a Retailer
My Account